


## Model No.US053D CORDLESS GARDEN SPRAYER



Nr.	Part nr.	Name
001	PR00000128	Draagriem
002	PR00000206	Label DUS054
003	PR00000214	Label US053D
004	PR00000183	Parker 4x16 DUS054
005	PR00000182	Parker ST2,9x12 DUS053/54D
006	PR00000189	Houder DUS053
007	PR00000129	Motorhuisset DUS053
008	PR00000183	Parker 4x16 DUS054
009	PR00000185	Batterijhuis DUS053
010	PR00000130	Montagebord DUS054
011	PR00000131	Bordveer DUS053 SET
012	PR00000132	Parker 4x12mm DUS054
013	PR00000133	Label indicatie DUS054
014	PR00000134	Circuit DUS053
015	PR00000135	Circuit US053D
016	PR00000185	Batterijhuis DUS053
017	PR00000183	Parker 4x16 DUS054
018	PR00000136	Schakelaar DUS054
019	PR00000137	Sproeikop DUS054 P
020	PR00000186	O-ring 6x2 DUS054
021	PR00000138	Spuitmondhouder DUS054 P
022	PR00000186	O-ring 6x2 DUS054
023	PR00000186	O-ring 6x2 DUS054
024	PR00000139	Verbinder DUS054 P
025	PR00000186	O-ring 6x2 DUS054
026	PR00000140	Eindkap DUS054 P
027	PR00000186	O-ring 6x2 DUS054
028	PR00000141	Stelknop DUS054 P
029	PR00000142	Neusstuk
030	PR00000143	Pakking 9x17x2 DUS054
031	PR00000144	Draaghaak
032	PR00000145	Spuitwand DUS053/54D
033	PR00000146	O-ring 4,5x1,5 DUS054
034	PR00000147	Filterset DUS053/54D
035	PR00000148	Handgreepschakeling DUS053/54D
036	PR00000149	O-ring 8x1,8 DUS054
037	PR00000150	Veer DUS054
038	PR00000204	O-ring 6x2 DUS054
039	PR00000205	O-ring 3x1 DUS054
040	PR00000151	Klepas DUS054
041	PR00000190	O-ring DUS053/54D
042	PR00000152	Sluitkap DUS054
043	PR00000182	Parker ST2,9x12 DUS053/54D
044	PR00000153	Handgreepset DUS053/54D
045	PR00000182	Parker ST2,9x12 DUS053/54D
046	PR00000154	Spuitslang DUS053/54D

Nr.	Part nr.	Name
047	PR00000155	Spuitslangklem DUS053/54D
048	PR00000184	Slangklem L DUS053/54D P
049	PR00000211	Label let op DUS054
050	PR00000182	Parker ST2,9x12 DUS053/54D
051	PR00000189	Houder DUS053
052	PR00000157	Label 12v US053D
053	PR00000129	Motorhuisset DUS053
054	PR00000158	Pakking batterijkap DUS053
055	PR00000159	Batterijafkapknop DUS053/54D
056	PR00000160	Veer DUS053/54D
057	PR00000161	Batterijafkap DUS053
058	PR00000162	Drukknop DUS053/54D
059	PR00000007	Schroef
060	PR00000163	As DUS053/54D
061	PR00000183	Parker 4x16 DUS054
062	PR00000164	Motorsteun DUS053/54D
063	PR00000165	Dempingsring DUS054
064	PR00000183	Parker 4x16 DUS054
065	PR00000166	Inlaatconnector DUS054
066	PR00000188	Slangklem DUS054
067	PR00000187	Slang 55mm DUS054 P
068	PR00000167	Veer DUS054
069	PR00000188	Slangklem DUS054
070	PR00000190	O-ring DUS053/54D
071	PR00000168	Waterpomp US053D
072	PR00000184	Slangklem L DUS053/54D P
073	PR00000187	Slang 55mm DUS054 P
074	PR00000187	Slang 55mm DUS054 P
075	PR00000184	Slangklem L DUS053/54D P
076	PR00000188	Slangklem DUS054
077	PR00000169	Controleklep DUS054
078	PR00000170	Doorvoerkraan DUS054
079	PR00000171	Pomp DUS053
080	PR00000183	Parker 4x16 DUS054
081	PR00000172	Moederbord DUS053/54D
082	PR00000183	Parker 4x16 DUS054
083	PR00000173	O-ring 17x2 DUS053/54D
084	PR00000186	O-ring 6x2 DUS054
085	PR00000174	Borgknopkap DUS053/54D
086	PR00000175	Pakkingschijf DUS053/54D
087	PR00000176	Zuigbuis DUS053/54D
088	PR00000177	Filter DUS053/54D
089	PR00000178	Tank DUS053/54D
090	PR00000179	O-ring 34x3,5 DUS054
091	PR00000180	Maatkap DUS053/54D
092	PR00000181	Filterpatroon DUS053/54D